AIRFIELD NAME		September 25				Dl	JNKESWELL	EGTU	West	
CALLSIGN		Dunkeswell Radio						123.480		
CALLSIGN		EGTU_R_TWR						Elev. 839ft		
LOCATION		Lat N050.13.16.000					Long W003.14.05.000	Conspicuity		
LOCATION GEO.		14nm				NΕ	of EXETER	QFE= QNH-28 HPscls		
CHART SOURCE		NATS FREE-FALL Parachuting normally takes place Thursdays to Sundays, + Bank hols.							nols.	
METAR AIRPORT		EGTE	GTE 119.330 AGRO will advise with airfield information. "Parachuting in pro-						"	
NAV AIDS	NONE Fixed wing may enter the ATZ, remain clear of OVERHEAD and DEADSIDE									
RUNWAY	Headings		Dimensio	ns	Surface		"Canopies in the Air" KEEP a SHAR	P LOOKOUT. AE	OVISE	
	04 / 22		968m x 46m		Asphalt		leaving the ATZ to the south. HELICOPTERS see below			
	17 / 35		UNLICENS	ISED Aspha		"Canopies on the ground" Sky now clear. More below.				
AIRSPACE	CLASS G		Transition	nsition level 3000ft		Airspace above is Class C Base Alt 10500 Airway N90				
CIRCUITS	UITS 800ft		Runway 04 - RH: 22 LH			ALL A/C JOIN CIRCUIT DOWNWIND OR BASE, During Parachuting				
NO FLY	Avoid overflying Dunkeswell Village below 500ft QFE. Keep clear of the Gliding site at all times									
LOCAL	Glider launching 1.7nm West-South-West, as shown below. Remain well clear AT ALL TIMES									
HAZARDS	Caution 3 radio masts up to 1000ft within ATZ. Caution Earth, thresholds 04 and 35.									
HELICOPTER OPERATIONS	Arrivals from North; NOT below 500ft QFE: Circuits as for Fixed Wing A/C									
	HELIO landing area, 'H', grass triangle, in line with 22 numbers. Depart to south not BELOW 500ft.									
	NO rotors turning within ATZ during parachuting. Call for rotor start, if Parachuting in progress.									
SPECIAL RULES	If no parachuting in hand, AGO will include in A/F information – "No parachuting in progress."									
	Fixed wing will then execute Standard Overhead Joins.									
	NO STRAIGHT IN approaches unless authorised. NO ORBITS within ATZ; EXTEND upwind or downwind									
REMARKS	Outer grass areas used for Sheep grazing.									
	Large paved area NW of runway and Road IS NOT PART OF RUNWAY									
	" Canopies OPEN"= Parachutes descending, DO NOT ENTER ATZ. "Canopies on the ground" = Clear.									

